

ashika®



**BIG END
BEARINGS
BRONZINE DI
BIELLA**




CATALOGUE
FOR CARS AND COMMERCIAL
VEHICLES

CATALOGO
PER AUTOMOBILI E VEICOLI
COMMERCIALI

www.ashika.it


82-1007GP

OE: 12111-09405 | ENGINE: J



82-1029G2


OE: 12117Y5211 | ENGINE: SD25



NISSAN PICK UP (720) 2.2
D[01.1982-01.1984](Diesel)
NISSAN PICK UP (720) 2.3
D[04.1983-03.1986](Diesel)
NISSAN PICK UP (720) 2.5 D
4WD[04.1983-03.1986](Diesel)
NISSAN PICK UP (D21) 2.3
D[09.1985-08.1988](Diesel)

82-1029G5

OE: 12117Y5212 | ENGINE: SD25



NISSAN PICK UP (720) 2.2
D[01.1982-01.1984](Diesel)
NISSAN PICK UP (720) 2.3
D[04.1983-03.1986](Diesel)
NISSAN PICK UP (720) 2.5 D
4WD[04.1983-03.1986](Diesel)
NISSAN PICK UP (D21) 2.3
D[09.1985-08.1988](Diesel)

82-1029GP

OE: 12117-Y5210 | ENGINE: SD25



NISSAN PICK UP (720) 2.2
D[01.1982-01.1984](Diesel)
NISSAN PICK UP (720) 2.3
D[04.1983-03.1986](Diesel)
NISSAN PICK UP (720) 2.5 D
4WD[04.1983-03.1986](Diesel)
NISSAN PICK UP (D21) 2.3
D[09.1985-08.1988](Diesel)

82-1032G2

| ENGINE: G161



82-1035A

OE: 13202-31020 | ENGINE: 12R



DAIHATSU TAFT 1.6 D 4x4 (F20, F25)
[09.1976-02.1985](Diesel)
TOYOTA HIACE I Furgonato (RH1_,
LH3_, RH3_, RH2_, LH2_, L 1.6
(RH20-30)[02.1977-03.1983](Benzina)
TOYOTA HIACE I Wagon (LH1_, RH1_,
LH3_, RH3_, LH2_, RH2_)
1.6[02.1977-11.1982](Benzina)

82-1035A2


OE: 1320331020 | ENGINE: 12R



DAIHATSU TAFT 1.6 D 4x4 (F20, F25)
[09.1976-02.1985](Diesel)
TOYOTA HIACE I Furgonato (RH1_,
LH3_, RH3_, RH2_, LH2_, L 1.6
(RH20-30)[02.1977-03.1983](Benzina)
TOYOTA HIACE I Wagon (LH1_, RH1_,
LH3_, RH3_, LH2_, RH2_)
1.6[02.1977-11.1982](Benzina)

82-1044G2

| ENGINE: LD20II



NISSAN BLUEBIRD (910) 2.0
D[01.1980-12.1983](Diesel)
NISSAN BLUEBIRD (910) 2.0
TD[01.1983-09.1983](Diesel)
NISSAN BLUEBIRD (B610)
1.8[07.1974-11.1979](Benzina)
NISSAN BLUEBIRD (T72, T12) 2.0 D
(SLT72, T12)[03.1986-12.1990](Diesel)

82-1044GP

OE: 12111-R2010 | ENGINE: LD20II



NISSAN BLUEBIRD (910) 2.0
D[01.1980-12.1983](Diesel)
NISSAN BLUEBIRD (910) 2.0
TD[01.1983-09.1983](Diesel)
NISSAN BLUEBIRD (B610)
1.8[07.1974-11.1979](Benzina)
NISSAN BLUEBIRD (T72, T12) 2.0 D
(SLT72, T12)[03.1986-12.1990](Diesel)

82-1045G2

| ENGINE: A10



NISSAN CHERRY (E10) I
1.0[09.1970-09.1978](Benzina)
NISSAN CHERRY II Coupé (N10)
1.2[08.1978-07.1981](Benzina)
NISSAN CHERRY II Hatchback (N10)
1.2[08.1978-07.1981](Benzina)
NISSAN CHERRY II Traveller (VN10)
1.2[10.1978-07.1981](Benzina)

82-1056G2

| ENGINE: K



TOYOTA 1000 (KP30_)
1.0[04.1969-19.7802](Benzina)
TOYOTA 1000 Furgonato (KP36V_)
1.0[04.1969-19.8808](Benzina)
TOYOTA COROLLA (KE) 1.2 (KE20,
KE25)[10.1972-07.1979](Benzina)
TOYOTA COROLLA (KE) 1.2 (KE20,
KE25, KE30)[08.1974-12.1980](Benzina)

82-1058G2

| ENGINE: SD33



NISSAN PATROL Hardtop (K160) 3.2 TD
(K160)[07.1983-08.1988](Diesel)
NISSAN PATROL Hardtop (K160) 3.3 D
(K160)[11.1979-08.1988](Diesel)
NISSAN PATROL Station Wagon (W160)
3.2 TD (W160)[07.1983-08.1988](Diesel)
NISSAN PATROL Station Wagon (W160)
3.3 D (W160)[11.1979-08.1988](Diesel)

82-1058G5

| ENGINE: SD33



NISSAN PATROL Hardtop (K160) 3.2 TD (K160)[07.1983-08.1988](Diesel)
 NISSAN PATROL Hardtop (K160) 3.3 D (K160)[11.1979-08.1988](Diesel)
 NISSAN PATROL Station Wagon (W160) 3.2 TD (W160)[07.1983-08.1988](Diesel)
 NISSAN PATROL Station Wagon (W160) 3.3 D (W160)[11.1979-08.1988](Diesel)

82-1058GP

| OE: 12117-37504 | ENGINE: SD33



NISSAN PATROL Hardtop (K160) 3.2 TD (K160)[07.1983-08.1988](Diesel)
 NISSAN PATROL Hardtop (K160) 3.3 D (K160)[11.1979-08.1988](Diesel)
 NISSAN PATROL Station Wagon (W160) 3.2 TD (W160)[07.1983-08.1988](Diesel)
 NISSAN PATROL Station Wagon (W160) 3.3 D (W160)[11.1979-08.1988](Diesel)

82-1070G2

| ENGINE: C223



ISUZU CAMPO (KB) 2.2 D (KBD27) [01.1983-12.1991](Diesel)
 ISUZU CAMPO (KB) 2.2 D (KBD27) [04.1986-12.1990](Diesel)
 ISUZU CAMPO (KB) 2.2 D 4WD (KBD42, KBD47)[01.1983-12.1990](Diesel)
 ISUZU TROOPER (UBS) 2.2 D 4x4[05.1984-12.1989](Diesel)

82-1070G5

| ENGINE: C223



ISUZU CAMPO (KB) 2.2 D (KBD27) [01.1983-12.1991](Diesel)
 ISUZU CAMPO (KB) 2.2 D (KBD27) [04.1986-12.1990](Diesel)
 ISUZU CAMPO (KB) 2.2 D 4WD (KBD42, KBD47)[01.1983-12.1990](Diesel)
 ISUZU TROOPER (UBS) 2.2 D 4x4[05.1984-12.1989](Diesel)

82-1070GP

| OE: 5-12271-005 | ENGINE: C223



ISUZU CAMPO (KB) 2.2 D (KBD27) [01.1983-12.1991](Diesel)
 ISUZU CAMPO (KB) 2.2 D (KBD27) [04.1986-12.1990](Diesel)
 ISUZU CAMPO (KB) 2.2 D 4WD (KBD42, KBD47)[01.1983-12.1990](Diesel)
 ISUZU TROOPER (UBS) 2.2 D 4x4[05.1984-12.1989](Diesel)

82-1075G2

| ENGINE: XA



82-1075GP

| OE: 0527-23-105 | ENGINE: XA



ISUZU CAMPO (KB) 2.2 D (KBD27) [01.1983-12.1991](Diesel)
 ISUZU CAMPO (KB) 2.2 D (KBD27) [04.1986-12.1990](Diesel)
 ISUZU CAMPO (KB) 2.2 D 4WD (KBD42, KBD47)[01.1983-12.1990](Diesel)
 ISUZU TROOPER (UBS) 2.2 D 4x4[05.1984-12.1989](Diesel)

82-1080A

| OE: 13202-47011 | ENGINE: H



TOYOTA LAND CRUISER (_J4_) 3.6 D (HJ45_V)[04.1979-07.1980](Diesel)
 TOYOTA LAND CRUISER (_J4_) 4.0 D (HJ47_V)[08.1980-10.1984](Diesel)
 TOYOTA LAND CRUISER (_J6_) 4.0 Diesel (HJ60)[01.1982-12.1985](Diesel)
 TOYOTA LAND CRUISER (_J6_) 4.0 Diesel (HJ60)[10.1982-12.1989](Diesel)

82-1080A2

| OE: 1320468050 | ENGINE: H



TOYOTA LAND CRUISER (_J4_) 3.6 D (HJ45_V)[04.1979-07.1980](Diesel)
 TOYOTA LAND CRUISER (_J4_) 4.0 D (HJ47_V)[08.1980-10.1984](Diesel)
 TOYOTA LAND CRUISER (_J6_) 4.0 Diesel (HJ60)[01.1982-12.1985](Diesel)
 TOYOTA LAND CRUISER (_J6_) 4.0 Diesel (HJ60)[10.1982-12.1989](Diesel)

82-1084G2

| ENGINE: PD6



82-1085A

| OE: MD002813 | ENGINE: 4 D 65



MITSUBISHI CELESTE (A7_) 1.6 ST (A73)[01.1977-06.1981](Benzina)
 MITSUBISHI COLT II (C1_A) 1.8 GL Diesel (C14A)[02.1984-09.1986](Diesel)
 MITSUBISHI COLT II (C1_A) 1.8 GL Diesel (C14A)[09.1986-04.1988](Diesel)
 MITSUBISHI COLT III (C5_A) 1.8 Diesel GLX (C54A)[04.1988-05.1992](Diesel)

82-1085A2

| OE: MD327503 | ENGINE: 4 D 65



MITSUBISHI CELESTE (A7_) 1.6 ST (A73)[01.1977-06.1981](Benzina)
 MITSUBISHI COLT II (C1_A) 1.8 GL Diesel (C14A)[02.1984-09.1986](Diesel)
 MITSUBISHI COLT II (C1_A) 1.8 GL Diesel (C14A)[09.1986-04.1988](Diesel)
 MITSUBISHI COLT III (C5_A) 1.8 Diesel GLX (C54A)[04.1988-05.1992](Diesel)

82-1085A5

| ENGINE: 4 D 65



1085A5

MITSUBISHI CELESTE (A7_) 1.6 ST
 (A73)[01.1977-06.1981](Benzina)
 MITSUBISHI COLT II (C1_A) 1.8 GL
 Diesel (C14A)[02.1984-09.1986](Diesel)
 MITSUBISHI COLT II (C1_A) 1.8 GL
 Diesel (C14A)[09.1986-04.1988](Diesel)
 MITSUBISHI COLT III (C5_A) 1.8 Diesel
 GLX (C54A)[04.1988-05.1992](Diesel)

82-1103GP


| OE: 8-94218-061 | ENGINE: G200



1103GP

82-1117GP

| OE: 13202-25010 | ENGINE: T



1117GP

DAIHATSU CHARMANT (A) 1.6 (A45)
 [12.1981-09.1984](Benzina)
 TOYOTA CARINA (TA1_)
 1.6[02.1976-03.1978](Benzina)
 TOYOTA CARINA (TA4L, TA6_L) 1.6
 (TA4L, TA60L)[01.1978-09.1983](Benzina)
 TOYOTA CARINA (TA4L, TA6_L)
 1.8[01.1978-05.1983](Benzina)

82-1121A

| OE: 13202-56010 | ENGINE: B



1121A

TOYOTA LAND CRUISER (_J4_) 3.0 D
 (BJ40_V, BJ43_)[03.1969-10.1984]
 (Diesel)

82-1121A2

| OE: 1320456010 | ENGINE: B



1121A2

TOYOTA LAND CRUISER (_J4_) 3.0 D
 (BJ40_V, BJ43_)[03.1969-10.1984]
 (Diesel)

82-1121A5

| OE: 1320556010 | ENGINE: B



1121A5

TOYOTA LAND CRUISER (_J4_) 3.0 D
 (BJ40_V, BJ43_)[03.1969-10.1984]
 (Diesel)

82-1131A

| OE: 1115A111 | ENGINE: 4 D 55



GASOLONE GASOLONE 35 2.5 D[-]
 (Diesel)
 HYUNDAI GALLOPER I 2.5 TD
 intercooler[08.1991-07.1998](Diesel)
 HYUNDAI GALLOPER I 2.5
 TD[08.1991-07.1998](Diesel)
 HYUNDAI GALLOPER II (JK-01) 2.5 TCi
 D[08.1998-20.0312](Diesel)

82-1131A2

| OE: MD026430 | ENGINE: 4 D 55



GASOLONE GASOLONE 35 2.5 D[-]
 (Diesel)
 HYUNDAI GALLOPER I 2.5 TD
 intercooler[08.1991-07.1998](Diesel)
 HYUNDAI GALLOPER I 2.5
 TD[08.1991-07.1998](Diesel)
 HYUNDAI GALLOPER II (JK-01) 2.5 TCi
 D[08.1998-20.0312](Diesel)

82-1131A5


| OE: MD026430 | ENGINE: 4 D 55



GASOLONE GASOLONE 35 2.5 D[-]
 (Diesel)
 HYUNDAI GALLOPER I 2.5 TD
 intercooler[08.1991-07.1998](Diesel)
 HYUNDAI GALLOPER I 2.5
 TD[08.1991-07.1998](Diesel)
 HYUNDAI GALLOPER II (JK-01) 2.5 TCi
 D[08.1998-20.0312](Diesel)

82-1133G2

| ENGINE: 6R



1133G2

TOYOTA CELICA (RA2_, TA2_)
 2.0[10.1975-07.1977](Benzina)
 TOYOTA CELICA (TA60, RA40, RA6_) 2.0
 XT (RA40)[01.1980-07.1981](Benzina)
 TOYOTA CELICA (TA60, RA40, RA6_) 2.0
 XT (RA40)[02.1979-07.1981](Benzina)
 TOYOTA CELICA (TA60, RA40, RA6_) 2.0
 XT (RA61)[02.1982-08.1985](Benzina)

82-1133GP

| OE: 13202-38011 | ENGINE: 6R



1133GP

TOYOTA CELICA (RA2_, TA2_)
 2.0[10.1975-07.1977](Benzina)
 TOYOTA CELICA (TA60, RA40, RA6_) 2.0
 XT (RA40)[01.1980-07.1981](Benzina)
 TOYOTA CELICA (TA60, RA40, RA6_) 2.0
 XT (RA40)[02.1979-07.1981](Benzina)
 TOYOTA CELICA (TA60, RA40, RA6_) 2.0
 XT (RA61)[02.1982-08.1985](Benzina)

82-1134G2

| ENGINE: EB1



1134G2

HONDA CIVIC I Hatchback (SB) 1200
 (SB1)[07.1972-02.1977](Benzina)
 HONDA CIVIC I Hatchback (SB) 1300 L
 (SS)[09.1979-09.1983](Benzina)
 HONDA CIVIC I Tre volumi (SF) 1300
 L[09.1980-09.1983](Benzina)
 HONDA CIVIC I Tre volumi (SF) 1300
 S[10.1979-12.1984](Benzina)

82-1134GP


OE: 13211-634-003 | ENGINE: EB1



HONDA CIVIC I Hatchback (SB) 1200 (SB1)[07.1972-02.1977](Benzina)
 HONDA CIVIC I Hatchback (SB) 1300 L (SS)[09.1979-09.1983](Benzina)
 HONDA CIVIC I Tre volumi (SF) 1300 L[09.1980-09.1983](Benzina)
 HONDA CIVIC I Tre volumi (SF) 1300 S[10.1979-12.1984](Benzina)

82-1141A2

ENGINE: NA



MAZDA 616 1.6[06.1973-02.1978] (Benzina)
 MAZDA 626 I (CB) 1.6[05.1979-05.1982] (Benzina)
 MAZDA 818 Station wagon 1.6[01.1977-10.1978](Benzina)

82-1141A5

ENGINE: NA



MAZDA 616 1.6[06.1973-02.1978] (Benzina)
 MAZDA 626 I (CB) 1.6[05.1979-05.1982] (Benzina)
 MAZDA 818 Station wagon 1.6[01.1977-10.1978](Benzina)

82-1142GP

OE: 13211-PC1-003 | ENGINE: EB5



82-1158A

OE: 13202-87305 | ENGINE: DL



DAIHATSU ROCKY Hard Top (F7, F8) 2.8 D[02.1985-19.9812](Diesel)
 DAIHATSU ROCKY Hard Top (F7, F8) 2.8 TD[05.1993-19.9812](Diesel)
 DAIHATSU ROCKY Hard Top (F7, F8) 2.8 TD[09.1991-19.9812](Diesel)
 DAIHATSU ROCKY Hard Top (F7, F8) 2.8 TD[12.1987-04.1993](Diesel)

82-1158A2

OE: 1320387305 | ENGINE: DL



DAIHATSU ROCKY Hard Top (F7, F8) 2.8 D[02.1985-19.9812](Diesel)
 DAIHATSU ROCKY Hard Top (F7, F8) 2.8 TD[05.1993-19.9812](Diesel)
 DAIHATSU ROCKY Hard Top (F7, F8) 2.8 TD[09.1991-19.9812](Diesel)
 DAIHATSU ROCKY Hard Top (F7, F8) 2.8 TD[12.1987-04.1993](Diesel)

82-1168A

OE: B3Y0-11-SE0 | ENGINE: B1



KIA PRIDE (DA) 1.1 i[01.1991-20.0010] (Benzina)
 MAZDA 121 I (DA) 1.1[10.1987-10.1990] (Benzina)
 MAZDA 121 I (DA) 1.3[04.1989-10.1990] (Benzina)
 MAZDA 121 I (DA) 1.3[10.1987-06.1991] (Benzina)

82-1168A2

ENGINE: B1



KIA PRIDE (DA) 1.1 i[01.1991-20.0010] (Benzina)
 MAZDA 121 I (DA) 1.1[10.1987-10.1990] (Benzina)
 MAZDA 121 I (DA) 1.3[04.1989-10.1990] (Benzina)
 MAZDA 121 I (DA) 1.3[10.1987-06.1991] (Benzina)

82-1168A5

ENGINE: B1



KIA PRIDE (DA) 1.1 i[01.1991-20.0010] (Benzina)
 MAZDA 121 I (DA) 1.1[10.1987-10.1990] (Benzina)
 MAZDA 121 I (DA) 1.3[04.1989-10.1990] (Benzina)
 MAZDA 121 I (DA) 1.3[10.1987-06.1991] (Benzina)

82-1169A

OE: MD030516 | ENGINE: G11B



MINIBUSHI COLT I (A15_A) 1.2 GL (A151A)[12.1978-01.1984](Benzina)
 MINIBUSHI COLT I (A15_A) 1.4 GLX,GT (A152A)[05.1979-01.1984](Benzina)
 MINIBUSHI COLT II (C1_A) 1.3 EL, GL (C11A)[06.1986-04.1988](Benzina)
 MINIBUSHI COLT II (C1_A) 1.5 GLX (C12A)[09.1984-04.1988](Benzina)

82-1169A2

ENGINE: G11B



MINIBUSHI COLT I (A15_A) 1.2 GL (A151A)[12.1978-01.1984](Benzina)
 MINIBUSHI COLT I (A15_A) 1.4 GLX,GT (A152A)[05.1979-01.1984](Benzina)
 MINIBUSHI COLT II (C1_A) 1.3 EL, GL (C11A)[06.1986-04.1988](Benzina)
 MINIBUSHI COLT II (C1_A) 1.5 GLX (C12A)[09.1984-04.1988](Benzina)

82-1173G2

ENGINE: CA18



NISSAN 200 SX (S13) 1.8 Turbo[07.1988-11.1993](Benzina)
 NISSAN BLUEBIRD (910) 1.6[01.1980-11.1983](Benzina)
 NISSAN BLUEBIRD (T72, T12) 1.6[03.1986-06.1990](Benzina)
 NISSAN BLUEBIRD (T72, T12) 1.8 Turbo[12.1985-05.1990](Benzina)

82-1173G5

| ENGINE: CA18



NISSAN 200 SX (S13) 1.8
Turbo[07.1988-11.1993](Benzina)
NISSAN BLUEBIRD (910)
1.6[01.1980-11.1983](Benzina)
NISSAN BLUEBIRD (T72 , T12)
1.6[03.1986-06.1990](Benzina)
NISSAN BLUEBIRD (T72 , T12) 1.8
Turbo[12.1985-05.1990](Benzina)

82-1173GP

| ENGINE: CA18



NISSAN 200 SX (S13) 1.8
Turbo[07.1988-11.1993](Benzina)
NISSAN BLUEBIRD (910)
1.6[01.1980-11.1983](Benzina)
NISSAN BLUEBIRD (T72 , T12)
1.6[03.1986-06.1990](Benzina)
NISSAN BLUEBIRD (T72 , T12) 1.8
Turbo[12.1985-05.1990](Benzina)

82-1174G2

| ENGINE: E13



NISSAN CHERRY II Coupé (N10)
1.3[08.1981-09.1982](Benzina)
NISSAN CHERRY II Hatchback (N10)
1.3[08.1981-09.1982](Benzina)
NISSAN CHERRY II Hatchback (N10)
1.5[08.1981-12.1982](Benzina)
NISSAN CHERRY II Traveller (VN10)
1.3[09.1981-12.1983](Benzina)

82-1174G5

| ENGINE: E13



NISSAN CHERRY II Coupé (N10)
1.3[08.1981-09.1982](Benzina)
NISSAN CHERRY II Hatchback (N10)
1.3[08.1981-09.1982](Benzina)
NISSAN CHERRY II Hatchback (N10)
1.5[08.1981-12.1982](Benzina)
NISSAN CHERRY II Traveller (VN10)
1.3[09.1981-12.1983](Benzina)

82-1179A

| ENGINE: F10A



BEDFORD RASCAL Autobus
1.0[07.1986-06.1990](Benzina)
BEDFORD RASCAL Furgonato
1.0[07.1986-06.1990](Benzina)
DAEWOO MATIZ (KLYA) 0.8[09.1998-]
(Benzina)
DAEWOO TICO (KLY3)
0.8[01.1996-12.2000](Benzina)

82-1181GP

| ENGINE: S2



MAZDA B-SERIE (UD) 2.2
D[02.1982-12.1984](Diesel)
MAZDA E-SERIE Pianale piatto/Telaio
E2200 D[05.1981-02.1984](Diesel)

82-1190G2

| ENGINE: TD25



FORD MAVERICK (UDS, UNS) 2.7
TD[02.1993-08.1996](Diesel)
FORD MAVERICK (UDS, UNS) 2.7
TD[09.1996-04.1998](Diesel)
NISSAN CABSTAR 2.5D F22[10.1985-]
(Diesel)
NISSAN CABSTAR Pianale piatto/Telaio
(F22, H40) 2.5 TD (F22)[10.1982-06.1992]
(Diesel)

82-1190G5

| ENGINE: TD25



FORD MAVERICK (UDS, UNS) 2.7
TD[02.1993-08.1996](Diesel)
FORD MAVERICK (UDS, UNS) 2.7
TD[09.1996-04.1998](Diesel)
NISSAN CABSTAR 2.5D F22[10.1985-]
(Diesel)
NISSAN CABSTAR Pianale piatto/Telaio
(F22, H40) 2.5 TD (F22)[10.1982-06.1992]
(Diesel)

82-1190GP

| ENGINE: TD25



NISSAN PICK UP (D21) 2.5 D
4WD[03.1996-02.1998](Diesel)
NISSAN PICK UP (D21) 2.5 D
4WD[08.1987-02.1998](Diesel)
NISSAN PICK UP (D21) 2.5
D[08.1992-02.1998](Diesel)
NISSAN PICK UP (D21) 2.5
D[09.1987-02.1998](Diesel)

82-1192G2

| ENGINE: TD23



NISSAN URVAN Furgonato (E24) 2.3
D[01.1988-05.1997](Diesel)

82-1192G5

| ENGINE: TD23



NISSAN URVAN Furgonato (E24) 2.3
D[01.1988-05.1997](Diesel)

82-1192GP

| ENGINE: TD23



NISSAN URVAN Furgonato (E24) 2.3
D[01.1988-05.1997](Diesel)

82-1194GP

OE: 12111-54T10 | ENGINE: BD30



NISSAN ATLEON 120.35[09.2000-]
(Benzina)
NISSAN ATLEON 120.45[09.2003-]
(Benzina)
NISSAN ATLEON 120.56[09.2000-]
(Benzina)
NISSAN ATLEON 120.56[09.2003-]
(Benzina)

82-1195GP

OE: 12111-43G01-S6 | ENGINE: TD42



NISSAN PATROL GR I (Y60, GR) 4.2 Cat.
[11.1988-02.1998](Benzina)

82-1201GP

OE: 12111-02P00 | ENGINE: VG30



1201GP

82-1202A

OE: 12216-01B10 | ENGINE: MA10



1202A

82-1202A2


| ENGINE: MA10



1202A2

82-1203G5

OE: 12111-42L00 | ENGINE: RB20



1203G5

NISSAN PATROL Hardtop (K260)
3.0[03.1989-09.1993](Benzina)
NISSAN PATROL Hardtop (K260)
3.0[03.1989-10.1993](Benzina)
NISSAN PATROL Station Wagon (W260)
3.0 4x4[03.1989-10.1993](Benzina)
NISSAN SKYLINE (R32) 2.0 Turbo
4x4[03.1989-06.1993](Benzina)

82-1207A

OE: 12111-V7200 | ENGINE: RD28T



NISSAN LAUREL (JC32) 2.8
D[01.1985-12.1989](Diesel)
NISSAN PATROL GR I (Y60, GR) 2.8 TD
(Y60A)[09.1988-06.1997](Diesel)
NISSAN PATROL Hardtop (K260) 2.8
TD[05.1986-06.1990](Diesel)
NISSAN PATROL Station Wagon (W260)
2.8 TD[06.1989-11.1995](Diesel)

82-1207A2

| ENGINE: RD28T



NISSAN LAUREL (JC32) 2.8
D[01.1985-12.1989](Diesel)
NISSAN PATROL GR I (Y60, GR) 2.8 TD
(Y60A)[09.1988-06.1997](Diesel)
NISSAN PATROL Hardtop (K260) 2.8
TD[05.1986-06.1990](Diesel)
NISSAN PATROL Station Wagon (W260)
2.8 TD[06.1989-11.1995](Diesel)

82-1207A5

| ENGINE: RD28T



1207A5

NISSAN LAUREL (JC32) 2.8
D[01.1985-12.1989](Diesel)
NISSAN PATROL GR I (Y60, GR) 2.8 TD
(Y60A)[09.1988-06.1997](Diesel)
NISSAN PATROL Hardtop (K260) 2.8
TD[05.1986-06.1990](Diesel)
NISSAN PATROL Station Wagon (W260)
2.8 TD[06.1989-11.1995](Diesel)

82-1208A

OE: 12111-77A00 | ENGINE: GA16



1208A

NISSAN 100 NX (B13) 1.6
SR[09.1993-10.1994](Benzina)
NISSAN 100 NX (B13)
1.6[03.1990-10.1994](Benzina)
NISSAN ALMERA I (N15) 1.6
SLX[09.1995-07.2000](Benzina)
NISSAN ALMERA I (N15)
1.6[09.1995-07.2000](Benzina)

82-1208A2

| ENGINE: GA16



NISSAN 100 NX (B13) 1.6
SR[09.1993-10.1994](Benzina)
NISSAN 100 NX (B13)
1.6[03.1990-10.1994](Benzina)
NISSAN ALMERA I (N15) 1.6
SLX[09.1995-07.2000](Benzina)
NISSAN ALMERA I (N15)
1.6[09.1995-07.2000](Benzina)

82-1208A5

| ENGINE: GA16



NISSAN 100 NX (B13) 1.6
SR[09.1993-10.1994](Benzina)
NISSAN 100 NX (B13)
1.6[03.1990-10.1994](Benzina)
NISSAN ALMERA I (N15) 1.6
SLX[09.1995-07.2000](Benzina)
NISSAN ALMERA I (N15)
1.6[09.1995-07.2000](Benzina)

82-1209G2

| ENGINE: KA24



NISSAN TERRANO II (R20) 2.4
4WD[05.1996-01.2002](Benzina)
NISSAN TERRANO II (R20) 2.4
4WD[05.1996-20.0709](Benzina)
NISSAN TERRANO II (R20) 2.4 i 12V
4WD[02.1993-12.1997](Benzina)

82-1209GP

OE: 12111-40F00 | ENGINE: KA24



NISSAN TERRANO II (R20) 2.4
4WD[05.1996-01.2002](Benzina)
NISSAN TERRANO II (R20) 2.4
4WD[05.1996-20.0709](Benzina)
NISSAN TERRANO II (R20) 2.4 i 12V
4WD[02.1993-12.1997](Benzina)

82-1210A

OE: 12111-40V10 | ENGINE: VG30



NISSAN 300 ZX (Z31)
3.0[01.1984-12.1987](Benzina)
NISSAN MAXIMA II (J30) 3.0
i[10.1988-06.1994](Benzina)
NISSAN PICK UP (D21) 3.0 i V6
4WD[09.1990-02.1998](Benzina)
NISSAN TERRANO I (WD21) 2.7 TD
4WD[02.1989-02.1996](Diesel)

82-1213G2

| ENGINE: SR18



NISSAN 200 SX (S14) 2.0 i 16V
Turbo[10.1993-12.1999](Benzina)
NISSAN PRIMERA (P10) 2.0 16V
4x4[04.1991-06.1996](Benzina)
NISSAN PRIMERA (P10) 2.0
16V[06.1990-01.1996](Benzina)
NISSAN PRIMERA (P10) 2.0
GT[06.1990-01.1996](Benzina)

82-1213GP

OE: 12111-60J00 | ENGINE: SR18



NISSAN 200 SX (S14) 2.0 i 16V
Turbo[10.1993-12.1999](Benzina)
NISSAN PRIMERA (P10) 2.0 16V
4x4[04.1991-06.1996](Benzina)
NISSAN PRIMERA (P10) 2.0
16V[06.1990-01.1996](Benzina)
NISSAN PRIMERA (P10) 2.0
GT[06.1990-01.1996](Benzina)

82-1400A


OE: 13041-15010 | ENGINE: 7A-FE



TOYOTA CARINA E (_T19_) 1.8 (AT191)
[01.1995-09.1997](Benzina)
TOYOTA CARINA E Sportswagon (_T19_)
1.8 i (AT191_) [02.1995-09.1997](Benzina)
TOYOTA CARINA E Tre volumi (_T19_)
1.8 i 16V (AT191)[01.1995-09.1997]
(Benzina)

82-1401A

OE: 13202-58010 | ENGINE: 3B



TOYOTA DYNA Autobus (_U3_ _U2_) 3.4
D[08.1977-08.1987](Diesel)
TOYOTA DYNA Pianale piatto/Telaio 3.4
D[09.1984-08.1987](Diesel)
TOYOTA LAND CRUISER (PZJ7_ _KZJ7_ _
HZJ7_ _BJ7_ _LJ7_ _RJ7 3.4 D (BJ70_V,
BJ73_)[11.1984-12.1996](Die

82-1401A2

| ENGINE: 3B



TOYOTA DYNA Autobus (_U3_ _U2_) 3.4
D[08.1977-08.1987](Diesel)
TOYOTA DYNA Pianale piatto/Telaio 3.4
D[09.1984-08.1987](Diesel)
TOYOTA LAND CRUISER (PZJ7_ _KZJ7_ _
HZJ7_ _BJ7_ _LJ7_ _RJ7 3.4 D (BJ70_V,
BJ73_)[11.1984-12.1996](Die

82-1404A2

| ENGINE: 1S



TOYOTA CAMRY Station Wagon (_V2_)
1.8 (SV20_)[11.1986-08.1989](Benzina)

82-1406A

OE: 13041-54013 | ENGINE: 2L



TOYOTA CRESSIDA Station Wagon (X6K,
MX62) 2.2 D[09.1980-04.1985](Diesel)
TOYOTA CRESSIDA Tre volumi (_X6_)
2.2 D (LX60)[09.1980-04.1985](Diesel)
TOYOTA HIACE I Furgonato (RH1_ _
LH3_ _RH3_ _RH2_ _LH2_ _L 2.2 D
(LH20-30)[01.1979-03.1983](Diesel)

82-1406A2

| ENGINE: 2L



TOYOTA CRESSIDA Station Wagon (X6K,
MX62) 2.2 D[09.1980-04.1985](Diesel)
TOYOTA CRESSIDA Tre volumi (_X6_)
2.2 D (LX60)[09.1980-04.1985](Diesel)
TOYOTA HIACE I Furgonato (RH1_ _
LH3_ _RH3_ _RH2_ _LH2_ _L 2.2 D
(LH20-30)[01.1979-03.1983](Diesel)

82-1406A5

| ENGINE: 2L



TOYOTA CRESSIDA Station Wagon (X6K,
MX62) 2.2 D[09.1980-04.1985](Diesel)
TOYOTA CRESSIDA Tre volumi (_X6_)
2.2 D (LX60)[09.1980-04.1985](Diesel)
TOYOTA HIACE I Furgonato (RH1_ _
LH3_ _RH3_ _RH2_ _LH2_ _L 2.2 D
(LH20-30)[01.1979-03.1983](Diesel)

82-1407A2

| ENGINE: 1Y



DAIHATSU ROCKY Hard Top (F7, F8)
2.0[02.1985-04.1993](Benzina)
DAIHATSU ROCKY Soft Top (F7, F8)
2.0[02.1985-04.1993](Benzina)
TOYOTA DYNA Pianale piatto/Telaio
2.0[09.1984-08.1987](Benzina)
TOYOTA HIACE II Furgonato (LH5_
YH7_, LH7_, LH6_, YH6_
1.8[12.1982-07.1989](Benzina)

82-1408A

| OE: 13041-64010 | ENGINE: 1C



TOYOTA CARINA (TA4L, TA6_L) 1.8
D[04.1982-09.1983](Diesel)
TOYOTA CARINA Station Wagon (TA4K,
TA6K) 1.8 D[04.1982-09.1983](Diesel)
TOYOTA COROLLA (_E7_) 1.8 D (CE70)
[01.1983-09.1983](Diesel)
TOYOTA COROLLA (_E8_) 1.8
D[06.1983-05.1988](Diesel)

82-1408A2

| ENGINE: 1C



TOYOTA CARINA (TA4L, TA6_L) 1.8
D[04.1982-09.1983](Diesel)
TOYOTA CARINA Station Wagon (TA4K,
TA6K) 1.8 D[04.1982-09.1983](Diesel)
TOYOTA COROLLA (_E7_) 1.8 D (CE70)
[01.1983-09.1983](Diesel)
TOYOTA COROLLA (_E8_) 1.8
D[06.1983-05.1988](Diesel)

82-1408A5

| ENGINE: 1C



TOYOTA CARINA (TA4L, TA6_L) 1.8
D[04.1982-09.1983](Diesel)
TOYOTA CARINA Station Wagon (TA4K,
TA6K) 1.8 D[04.1982-09.1983](Diesel)
TOYOTA COROLLA (_E7_) 1.8 D (CE70)
[01.1983-09.1983](Diesel)
TOYOTA COROLLA (_E8_) 1.8
D[06.1983-05.1988](Diesel)

82-1410G2

| ENGINE: 2A



DAIHATSU CHARMANT (A) 1.6 (A60)
[05.1986-07.1987](Benzina)
DAIHATSU CHARMANT (A) 1.6 (A60)
[08.1983-07.1987](Benzina)
DAIHATSU CHARMANT (A) 1.6 (A60)
[09.1985-07.1987](Benzina)
TOYOTA TERCEL (AL2_) 1.5
4WD[10.1982-01.1988](Benzina)

82-1410G5

| ENGINE: 2A



DAIHATSU CHARMANT (A) 1.6 (A60)
[05.1986-07.1987](Benzina)
DAIHATSU CHARMANT (A) 1.6 (A60)
[08.1983-07.1987](Benzina)
DAIHATSU CHARMANT (A) 1.6 (A60)
[09.1985-07.1987](Benzina)
TOYOTA TERCEL (AL2_) 1.5
4WD[10.1982-01.1988](Benzina)

82-1411A

| OE: 13041-54040 | ENGINE: 2L-T



METROCAB Taxi 2.4
TD[01.2001-20.0605](Diesel)
TOYOTA CRESSIDA Tre volumi (GX7_
MX73) 2.4 TD[01.1985-10.1988](Diesel)
TOYOTA DYNA 150 Pianale piatto/Telaio
(LY_) 3.0 D[09.1998-07.2001](Diesel)
TOYOTA DYNA Pianale piatto/Telaio
(KD_, LY_, TRY2_, KDY2_ 3.0
D4d[08.2001-](Diesel)

82-1411A2

| OE: 1304154040 | ENGINE: 2L-T



METROCAB Taxi 2.4
TD[01.2001-20.0605](Diesel)
TOYOTA CRESSIDA Tre volumi (GX7_
MX73) 2.4 TD[01.1985-10.1988](Diesel)
TOYOTA DYNA 150 Pianale piatto/Telaio
(LY_) 3.0 D[09.1998-07.2001](Diesel)
TOYOTA DYNA Pianale piatto/Telaio
(KD_, LY_, TRY2_, KDY2_ 3.0
D4d[08.2001-](Diesel)

82-1414G2

| ENGINE: 5M



82-1414G5

| ENGINE: 5M



82-1414GP

| OE: 13041-42010 | ENGINE: 5M



82-1415A

| OE: 13041-10021 | ENGINE: 1E



TOYOTA COROLLA (_E10_) 1.3 12V
(EE100_)[07.1992-04.1997](Benzina)
TOYOTA COROLLA (_E9_) 1.3 i (EE90)
[08.1989-04.1992](Benzina)
TOYOTA COROLLA Compact (_E10_) 1.3
12V (EE100_)[07.1992-05.1995](Benzina)
TOYOTA COROLLA Compact (_E9_) 1.3
(EE90)[08.1987-04.1992](Benzina)

82-1415A5

| ENGINE: 1E



TOYOTA COROLLA (_E10_) 1.3 12V
(EE100)[07.1992-04.1997](Benzina)
TOYOTA COROLLA (_E9_) 1.3 i (EE90)
[08.1989-04.1992](Benzina)
TOYOTA COROLLA Compact (_E10_) 1.3
12V (EE100)[07.1992-05.1995](Benzina)
TOYOTA COROLLA Compact (_E9_) 1.3
(EE90)[08.1987-04.1992](Benzina)

82-1416A

| OE: 13041-13040 | ENGINE: 2K



TOYOTA 1000 (KP30_)
1.0[04.1969-19.7802](Benzina)
TOYOTA 1000 Furgonato (KP36V_)
1.0[04.1969-19.8808](Benzina)
TOYOTA COROLLA (_E7_) 1.3 (KE70)
[02.1982-06.1983](Benzina)
TOYOTA COROLLA (_E7_) 1.3 (KE70)
[09.1979-06.1983](Benzina)

82-1416A2


| ENGINE: 2K



TOYOTA 1000 (KP30_)
1.0[04.1969-19.7802](Benzina)
TOYOTA 1000 Furgonato (KP36V_)
1.0[04.1969-19.8808](Benzina)
TOYOTA COROLLA (_E7_) 1.3 (KE70)
[02.1982-06.1983](Benzina)
TOYOTA COROLLA (_E7_) 1.3 (KE70)
[09.1979-06.1983](Benzina)


82-1419G2

| ENGINE: 3S




82-1419G5

| ENGINE: 3S



82-1419GP

| OE: 13041-88360 | ENGINE: 3S



82-1421A

| OE: 13041-64050 | ENGINE: 1C



TOYOTA CARINA E (_T19_) 2.0 D
(CT190)[04.1992-01.1996](Diesel)
TOYOTA CARINA E Sportswagon (_T19_)
2.0 D (CT190)[01.1993-01.1996](Diesel)
TOYOTA CARINA E Tre volumi (_T19_)
2.0 D (CT190)[08.1992-01.1996](Diesel)
TOYOTA COROLLA (_E10_) 2.0 D
(CE100)[07.1992-04.1997](Diesel)

82-1424A

| OE: 13041-11020 | ENGINE: 3E



82-1425G2

| ENGINE: 4A-GZE



82-1425G5

| ENGINE: 4A-GZE



82-1425GP

| OE: 13041-16070 | ENGINE: 4A-GZE



82-1428A2

| OE: 13041-56030-01 | ENGINE: B



TOYOTA DYNA 200 Pianale piatto/Telaio
3.0 D[01.1985-05.1995](Diesel)

82-1428A5

OE: 13041-56030-02 | ENGINE: B



TOYOTA DYNA 200 Pianale piatto/Telaio
3.0 D[01.1985-05.1995](Diesel)

82-1429A

OE: 13041-56040 | ENGINE: 3B



TOYOTA LAND CRUISER (PZJ7_, KZJ7_,
HZJ7_, BJ7_, LJ7_, RJ7 3.4 D (BJ70_V,
BJ73_)[11.1984-12.1996](Die

82-1429A2

| ENGINE: 3B



TOYOTA LAND CRUISER (PZJ7_, KZJ7_,
HZJ7_, BJ7_, LJ7_, RJ7 3.4 D (BJ70_V,
BJ73_)[11.1984-12.1996](Die

82-1429A5

| ENGINE: 3B



TOYOTA LAND CRUISER (PZJ7_, KZJ7_,
HZJ7_, BJ7_, LJ7_, RJ7 3.4 D (BJ70_V,
BJ73_)[11.1984-12.1996](Die

82-1434G2

OE: 13041-46010-01 | ENGINE: 1JZ



LEXUS GS (JZS147)
300[01.1993-08.1997](Benzina)
LEXUS GS (UZS161, JZS160) 300
T3[08.1997-10.2000](Benzina)
LEXUS GS (UZS161, JZS160)
300[10.2000-12.2004](Benzina)
LEXUS IS I (JCE1_, GXE1_)
300[09.2001-20.0507](Benzina)

82-1434G5

OE: 13041-46010-02 | ENGINE: 1JZ



LEXUS GS (JZS147)
300[01.1993-08.1997](Benzina)
LEXUS GS (UZS161, JZS160) 300
T3[08.1997-10.2000](Benzina)
LEXUS GS (UZS161, JZS160)
300[10.2000-12.2004](Benzina)
LEXUS IS I (JCE1_, GXE1_)
300[09.2001-20.0507](Benzina)

82-1434GP

OE: 13041-46010 | ENGINE: 1JZ



LEXUS GS (JZS147)
300[01.1993-08.1997](Benzina)
LEXUS GS (UZS161, JZS160) 300
T3[08.1997-10.2000](Benzina)
LEXUS GS (UZS161, JZS160)
300[10.2000-12.2004](Benzina)
LEXUS IS I (JCE1_, GXE1_)
300[09.2001-20.0507](Benzina)

82-1435A

OE: 13041-75010 | ENGINE: 1RZ



TOYOTA HIACE III Furgonato (YH7_,
LH6_, LH7_, LH5_, YH5_,
2.0[02.1990-08.2004](Benzina)
TOYOTA HIACE III Wagon (LH1_, RZH1_)
2.0 (RZH102)[08.1989-04.1998](Benzina)

82-1435A2

| ENGINE: 1RZ



TOYOTA HIACE III Furgonato (YH7_,
LH6_, LH7_, LH5_, YH5_,
2.0[02.1990-08.2004](Benzina)
TOYOTA HIACE III Wagon (LH1_, RZH1_)
2.0 (RZH102)[08.1989-04.1998](Benzina)

82-1436A

OE: 13041-17010 | ENGINE: 1H-Z



TOYOTA LAND CRUISER (PZJ7_, KZJ7_,
HZJ7_, BJ7_, LJ7_, RJ7 4.2 TD
(HZJ7_V)[01.1990-](Diesel)
TOYOTA LAND CRUISER 80 (_J8_) 4.2 D
(HZJ80_)[01.1990-12.1997](Diesel)
TOYOTA LAND CRUISER 80 (_J8_) 4.2
TD (HDJ80)[01.1990-12.1997](Diesel)
TOYOTA LAND CRUISER 80 (_J8_) 4.2
TD (HDJ80)[08.1992-12.1997](Diesel)

82-1436A2

| ENGINE: 1H-Z



TOYOTA LAND CRUISER (PZJ7_, KZJ7_,
HZJ7_, BJ7_, LJ7_, RJ7 4.2 TD
(HZJ7_V)[01.1990-](Diesel)
TOYOTA LAND CRUISER 80 (_J8_) 4.2 D
(HZJ80_)[01.1990-12.1997](Diesel)
TOYOTA LAND CRUISER 80 (_J8_) 4.2
TD (HDJ80)[01.1990-12.1997](Diesel)
TOYOTA LAND CRUISER 80 (_J8_) 4.2
TD (HDJ80)[08.1992-12.1997](Diesel)

82-1436A5

| ENGINE: 1H-Z



TOYOTA LAND CRUISER (PZJ7_, KZJ7_,
HZJ7_, BJ7_, LJ7_, RJ7 4.2 TD
(HZJ7_V)[01.1990-](Diesel)
TOYOTA LAND CRUISER 80 (_J8_) 4.2 D
(HZJ80_)[01.1990-12.1997](Diesel)
TOYOTA LAND CRUISER 80 (_J8_) 4.2
TD (HDJ80)[01.1990-12.1997](Diesel)
TOYOTA LAND CRUISER 80 (_J8_) 4.2
TD (HDJ80)[08.1992-12.1997](Diesel)

82-1437A

OE: 13041-65020 | ENGINE: 3VZ-FE



TOYOTA 4 RUNNER (RN10_, VZN13_, VZN10_, RN13_) 3.0 V6 (VZN 130)
[01.1990-10.1995](Benzina)
TOYOTA CAMRY (_CV1_, _XV1_, _V1_) 3.0 (VCV10)[06.1991-08.1996](Benzina)
TOYOTA CAMRY Station Wagon (_XV1_, _CV1_, _V10) 3.0 (VCV10)
[09.1991-07.1996](Benzina)

82-1440G2

OE: 13041-50020-02 | ENGINE: 1UZ-FE



LEXUS GS (UZS161, JZS160) 400[12.1997-11.2000](Benzina)
LEXUS LS (UCF10) 400[12.1989-12.1995](Benzina)
LEXUS LS (UCF20) 4.0[10.1997-12.2000](Benzina)
LEXUS LS (UCF20) 400[09.1997-20.0010](Benzina)

82-1602G2

OE: 8-94251-266-01 | ENGINE: 4ZB1



BEDFORD MIDI Autobus 1.8[09.1984-05.1988](Benzina)
BEDFORD MIDI Furgonato 1.8[09.1984-05.1988](Benzina)
ISUZU CAMPO (KB) 2.0 (KB23) [01.1983-03.1988](Benzina)
ISUZU CAMPO (KB) 2.0 (KB28) [06.1985-12.1988](Benzina)

82-1602G5

OE: 8-94251-266-02 | ENGINE: 4ZB1



BEDFORD MIDI Autobus 1.8[09.1984-05.1988](Benzina)
BEDFORD MIDI Furgonato 1.8[09.1984-05.1988](Benzina)
ISUZU CAMPO (KB) 2.0 (KB23) [01.1983-03.1988](Benzina)
ISUZU CAMPO (KB) 2.0 (KB28) [06.1985-12.1988](Benzina)

82-1603GP

OE: 9-12271-178 | ENGINE: 4BA1



82-1616G2

| ENGINE: 4FC1



ISUZU MIDI Autobus (94000, 98000) 2.0 TD (98000)[01.1989-19.9208](Diesel)
ISUZU MIDI Autobus (94000, 98000) 2.2 D (98000)[06.1988-19.9208](Diesel)
ISUZU MIDI Autobus (94000, 98000) 2.2 D 4WD (94000)[06.1988-19.9208](Diesel)
ISUZU MIDI Furgonato (98000N) 2.0 TD[09.1990-08.1992](Diesel)

82-1616GP

OE: 8-94221-167 | ENGINE: 4FC1



ISUZU MIDI Autobus (94000, 98000) 2.0 TD (98000)[01.1989-19.9208](Diesel)
ISUZU MIDI Autobus (94000, 98000) 2.2 D (98000)[06.1988-19.9208](Diesel)
ISUZU MIDI Autobus (94000, 98000) 2.2 D 4WD (94000)[06.1988-19.9208](Diesel)
ISUZU MIDI Furgonato (98000N) 2.0 TD[09.1990-08.1992](Diesel)

82-1620G2

| ENGINE: G200W



ISUZU TROOPER Fuoristrada aperto (UBS) 2.3 (UBS16)[11.1985-12.1991](Benzina)

82-1620GP

OE: 8-94251-266 | ENGINE: G200W



ISUZU TROOPER Fuoristrada aperto (UBS) 2.3 (UBS16)[11.1985-12.1991](Benzina)

82-1622G2

| ENGINE: 4JA1



ISUZU CAMPO (KB) 2.5 D (TFR54) [08.1988-](Diesel)
ISUZU CAMPO (KB) 2.5 D (KBD27) [01.1983-12.1990](Diesel)
ISUZU CAMPO (KB) 2.5 D 4WD (KBD47) [01.1983-12.1990](Diesel)
ISUZU D-MAX (8DH) 2.5 D 4x4[05.2002-20.1206](Diesel)

82-1622G5

OE: 894324159 | ENGINE: 4JA1



ISUZU CAMPO (KB) 2.5 D (TFR54) [08.1988-](Diesel)
ISUZU CAMPO (KB) 2.5 D (KBD27) [01.1983-12.1990](Diesel)
ISUZU CAMPO (KB) 2.5 D 4WD (KBD47) [01.1983-12.1990](Diesel)
ISUZU D-MAX (8DH) 2.5 D 4x4[05.2002-20.1206](Diesel)

82-1622GP

OE: 8-94125-747 | ENGINE: 4JA1



ISUZU CAMPO (KB) 2.5 D (TFR54) [08.1988-](Diesel)
ISUZU CAMPO (KB) 2.5 D (KBD27) [01.1983-12.1990](Diesel)
ISUZU CAMPO (KB) 2.5 D 4WD (KBD47) [01.1983-12.1990](Diesel)
ISUZU D-MAX (8DH) 2.5 D 4x4[05.2002-20.1206](Diesel)

82-1624A

E: 8-94314-253-0 | ENGINE: 15 D (4EC)



ISUZU GEMINI (JT) 1.5
D[02.1988-12.1990](Diesel)
ISUZU GEMINI (JT) 1.5
TD[02.1988-12.1990](Diesel)
ISUZU GEMINI Tre volumi (JT) 1.5
D[02.1988-12.1989](Diesel)
ISUZU GEMINI Tre volumi (JT) 1.5
TD[02.1988-12.1989](Diesel)

82-1624A2

| ENGINE: 15 D (4EC1)



ISUZU GEMINI (JT) 1.5
D[02.1988-12.1990](Diesel)
ISUZU GEMINI (JT) 1.5
TD[02.1988-12.1990](Diesel)
ISUZU GEMINI Tre volumi (JT) 1.5
D[02.1988-12.1989](Diesel)
ISUZU GEMINI Tre volumi (JT) 1.5
TD[02.1988-12.1989](Diesel)

82-1624A5


| ENGINE: 15 D (4EC1)



ISUZU GEMINI (JT) 1.5
D[02.1988-12.1990](Diesel)
ISUZU GEMINI (JT) 1.5
TD[02.1988-12.1990](Diesel)
ISUZU GEMINI Tre volumi (JT) 1.5
D[02.1988-12.1989](Diesel)
ISUZU GEMINI Tre volumi (JT) 1.5
TD[02.1988-12.1989](Diesel)

82-1627A

OE: 8-94440-093-2 | ENGINE: 4ZE1



ISUZU TROOPER Fuoristrada aperto
(UBS) 2.6 i (UBS17)[10.1987-12.1991]
(Benzina)

82-1627A2


| ENGINE: 4ZE1



ISUZU TROOPER Fuoristrada aperto
(UBS) 2.6 i (UBS17)[10.1987-12.1991]
(Benzina)

82-1627A5

| ENGINE: 4ZE1



ISUZU TROOPER Fuoristrada aperto
(UBS) 2.6 i (UBS17)[10.1987-12.1991]
(Benzina)

82-1807G2

| ENGINE: 4D30



82-1807GP

OE: ME999250 | ENGINE: 4D30



82-1822A

OE: MD105277 | ENGINE: 6G72



CHRYSLER VOYAGER II (ES) 3.0
i[01.1991-09.1995](Benzina)
MITSUBISHI 3000 GT (Z16A) 3.0 i 24V
4x4[01.1990-08.1999](Benzina)
MITSUBISHI PAJERO I (L04_G, L14_G)
3.0 V6 (L141G, L146G)[11.1988-11.1990]
(Benzina)

82-1822A2

| ENGINE: 6G72



CHRYSLER VOYAGER II (ES) 3.0
i[01.1991-09.1995](Benzina)
MITSUBISHI 3000 GT (Z16A) 3.0 i 24V
4x4[01.1990-08.1999](Benzina)
MITSUBISHI PAJERO I (L04_G, L14_G)
3.0 V6 (L141G, L146G)[11.1988-11.1990]
(Benzina)

82-1822A5

| ENGINE: 6G72



CHRYSLER VOYAGER II (ES) 3.0
i[01.1991-09.1995](Benzina)
MITSUBISHI 3000 GT (Z16A) 3.0 i 24V
4x4[01.1990-08.1999](Benzina)
MITSUBISHI PAJERO I (L04_G, L14_G)
3.0 V6 (L141G, L146G)[11.1988-11.1990]
(Benzina)

82-1825A

OE: MD143090 | ENGINE: G11B



MITSUBISHI COLT II (C1_A) 1.3 EL, GL
(C11A)[06.1986-04.1988](Benzina)
MITSUBISHI COLT II (C1_A) 1.5 GLX
(C12A)[09.1984-04.1988](Benzina)
MITSUBISHI COLT II (C1_A) 1.5 GLX
(C12A)[09.1985-04.1988](Benzina)
MITSUBISHI COLT III (C5_A) 1.3
GL[04.1988-12.1990](Benzina)

82-1825A2


| ENGINE: G11B



MITSUBISHI COLT II (C1_A) 1.3 EL, GL (C11A)[06.1986-04.1988](Benzina)
 MITSUBISHI COLT II (C1_A) 1.5 GLX (C12A)[09.1984-04.1988](Benzina)
 MITSUBISHI COLT II (C1_A) 1.5 GLX (C12A)[09.1985-04.1988](Benzina)
 MITSUBISHI COLT III (C5_A) 1.3 GL[04.1988-12.1990](Benzina)

82-1825A5

| ENGINE: G11B



MITSUBISHI COLT II (C1_A) 1.3 EL, GL (C11A)[06.1986-04.1988](Benzina)
 MITSUBISHI COLT II (C1_A) 1.5 GLX (C12A)[09.1984-04.1988](Benzina)
 MITSUBISHI COLT II (C1_A) 1.5 GLX (C12A)[09.1985-04.1988](Benzina)
 MITSUBISHI COLT III (C5_A) 1.3 GL[04.1988-12.1990](Benzina)

82-2004A

| OE: RF01-23-105 | ENGINE: RF46



MAZDA 626 II (GC) 1.6[11.1982-06.1987] (Benzina)
 MAZDA 626 II (GC) 2.0 D[01.1983-06.1987](Diesel)
 MAZDA 626 II (GC) 2.0[01.1986-09.1987] (Benzina)
 MAZDA 626 II (GC) 2.0[03.1983-09.1987] (Benzina)

82-2004A2

| ENGINE: RF46



MAZDA 626 II (GC) 1.6[11.1982-06.1987] (Benzina)
 MAZDA 626 II (GC) 2.0 D[01.1983-06.1987](Diesel)
 MAZDA 626 II (GC) 2.0[01.1986-09.1987] (Benzina)
 MAZDA 626 II (GC) 2.0[03.1983-09.1987] (Benzina)

82-2004A5

| ENGINE: RF46



MAZDA 626 II (GC) 1.6[11.1982-06.1987] (Benzina)
 MAZDA 626 II (GC) 2.0 D[01.1983-06.1987](Diesel)
 MAZDA 626 II (GC) 2.0[01.1986-09.1987] (Benzina)
 MAZDA 626 II (GC) 2.0[03.1983-09.1987] (Benzina)

82-2008A

| OE: B6Y0-11-SE0 | ENGINE: B6



MAZDA 323 C IV (BG) 1.6 16V[03.1991-10.1994](Benzina)
 MAZDA 323 C IV (BG) 1.8 16V 4WD[11.1991-12.1993](Benzina)
 MAZDA 323 F IV (BG) 1.6 16V[03.1991-10.1994](Benzina)
 MAZDA 323 F IV (BG) 1.8 16V[08.1989-07.1994](Benzina)

82-2008A2

| ENGINE: B6



MAZDA 323 C IV (BG) 1.6 16V[03.1991-10.1994](Benzina)
 MAZDA 323 C IV (BG) 1.8 16V 4WD[11.1991-12.1993](Benzina)
 MAZDA 323 F IV (BG) 1.6 16V[03.1991-10.1994](Benzina)
 MAZDA 323 F IV (BG) 1.8 16V[08.1989-07.1994](Benzina)

82-2008A5

| ENGINE: B6



MAZDA 323 C IV (BG) 1.6 16V[03.1991-10.1994](Benzina)
 MAZDA 323 C IV (BG) 1.8 16V 4WD[11.1991-12.1993](Benzina)
 MAZDA 323 F IV (BG) 1.6 16V[03.1991-10.1994](Benzina)
 MAZDA 323 F IV (BG) 1.8 16V[08.1989-07.1994](Benzina)

82-2009A

| OE: FEYA-11-SE0 | ENGINE: FE



MAZDA 626 II (GC) 2.0[01.1986-09.1987] (Benzina)
 MAZDA 626 II (GC) 2.0[03.1983-09.1987] (Benzina)
 MAZDA 626 II Hatchback (GC) 2.0[01.1986-09.1987](Benzina)
 MAZDA 626 II Hatchback (GC) 2.0[03.1983-09.1987](Benzina)

82-2009A2

| ENGINE: FE



MAZDA 626 II (GC) 2.0[01.1986-09.1987] (Benzina)
 MAZDA 626 II (GC) 2.0[03.1983-09.1987] (Benzina)
 MAZDA 626 II Hatchback (GC) 2.0[01.1986-09.1987](Benzina)
 MAZDA 626 II Hatchback (GC) 2.0[03.1983-09.1987](Benzina)

82-2009A5

| ENGINE: FE



MAZDA 626 II (GC) 2.0[01.1986-09.1987] (Benzina)
 MAZDA 626 II (GC) 2.0[03.1983-09.1987] (Benzina)
 MAZDA 626 II Hatchback (GC) 2.0[01.1986-09.1987](Benzina)
 MAZDA 626 II Hatchback (GC) 2.0[03.1983-09.1987](Benzina)

82-2010A

| OE: JEY1-11-SE0 | ENGINE: JE



MAZDA 929 III (HC) 3.0[06.1987-06.1991] (Benzina)

82-2010A5

| ENGINE: JE



MAZDA 929 III (HC) 3.0[06.1987-06.1991]
(Benzina)


82-2109G2

| ENGINE: W04D




82-2109G5

| ENGINE: W04D



82-2109GP

OE: 13041-78010 | ENGINE: W04D



82-2200G2

| ENGINE: A18A



HONDA CR-V I (RD) 2.0 16V (RD1, RD3)
[10.1995-12.2001](Benzina)

82-2200G5

| ENGINE: A18A



HONDA CR-V I (RD) 2.0 16V (RD1, RD3)
[10.1995-12.2001](Benzina)

82-2200GP


OE: 13211-PC6-003 | ENGINE: A18A



HONDA CR-V I (RD) 2.0 16V (RD1, RD3)
[10.1995-12.2001](Benzina)

82-2204G5

| ENGINE: D13C



HONDA CIVIC IV Hatchback (EC, ED, EE)
1.3 (EC8)[10.1987-12.1989](Benzina)
HONDA CIVIC IV Hatchback (EC, ED, EE)
1.3 16 V (EC8) Cat.[09.1989-09.1991]
(Benzina)
HONDA CIVIC IV Tre volumi (ED)
1.3[10.1987-12.1989](Benzina)
HONDA CIVIC V Hatchback (EG) 1.3 16V
(EG3)[10.1991-11.1995](Benzina)

82-2204GP

OE: 13211-PE0-003 | ENGINE: D13C



HONDA CIVIC IV Hatchback (EC, ED, EE)
1.3 (EC8)[10.1987-12.1989](Benzina)
HONDA CIVIC IV Hatchback (EC, ED, EE)
1.3 16 V (EC8) Cat.[09.1989-09.1991]
(Benzina)
HONDA CIVIC IV Tre volumi (ED)
1.3[10.1987-12.1989](Benzina)
HONDA CIVIC V Hatchback (EG) 1.3 16V
(EG3)[10.1991-11.1995](Benzina)

82-2205G2

| ENGINE: D15B



HONDA CIVIC I Shuttle (AN, AR) 1.5 (AN)
[10.1983-10.1987](Benzina)
HONDA CIVIC I Shuttle (AN, AR) 1.5
4WD (AR)[01.1985-10.1987](Benzina)
HONDA CIVIC II Shuttle (EE) 1.5 i 16V
(EE2)[01.1988-11.1991](Benzina)
HONDA CIVIC III Hatchback (AL, AJ, AG,
AH) 1.5 GL (AH)[10.1983-10.1987]
(Benzina)

82-2205GP

OE: 13211-PE1-003 | ENGINE: D15B



HONDA CIVIC I Shuttle (AN, AR) 1.5 (AN)
[10.1983-10.1987](Benzina)
HONDA CIVIC I Shuttle (AN, AR) 1.5
4WD (AR)[01.1985-10.1987](Benzina)
HONDA CIVIC II Shuttle (EE) 1.5 i 16V
(EE2)[01.1988-11.1991](Benzina)
HONDA CIVIC III Hatchback (AL, AJ, AG,
AH) 1.5 GL (AH)[10.1983-10.1987]
(Benzina)

82-2208G2

| ENGINE: D15B



HONDA CIVIC II Shuttle (EE) 1.5 i 16V
(EE2)[01.1988-11.1991](Benzina)
HONDA CIVIC II Shuttle (EE) 1.6 i 16V
4WD (EE4)[01.1988-02.1995](Benzina)
HONDA CIVIC II Shuttle (EE) 1.6 i 16V
4WD (EE4)[01.1988-12.1989](Benzina)
HONDA CIVIC IV Hatchback (EC, ED, EE)
1.5 i 16V (ED6)[10.1988-09.1991]
(Benzina)

82-2208G5

| ENGINE: D15



HONDA CIVIC II Shuttle (EE) 1.5 i 16V (EE2)[01.1988-11.1991](Benzina)
 HONDA CIVIC II Shuttle (EE) 1.6 i 16V 4WD (EE4)[01.1988-02.1995](Benzina)
 HONDA CIVIC II Shuttle (EE) 1.6 i 16V 4WD (EE4)[01.1988-12.1989](Benzina)
 HONDA CIVIC IV Hatchback (EC, ED, EE) 1.5 i 16V (ED6)[10.1988-09.1991](Benzina)

82-2208GP

| OE: 13211-PG6-003 | ENGINE: D15



HONDA CIVIC II Shuttle (EE) 1.5 i 16V (EE2)[01.1988-11.1991](Benzina)
 HONDA CIVIC II Shuttle (EE) 1.6 i 16V 4WD (EE4)[01.1988-02.1995](Benzina)
 HONDA CIVIC II Shuttle (EE) 1.6 i 16V 4WD (EE4)[01.1988-12.1989](Benzina)
 HONDA CIVIC IV Hatchback (EC, ED, EE) 1.5 i 16V (ED6)[10.1988-09.1991](Benzina)

82-2210GP

| OE: 13211-PH7-013 | ENGINE: C25A



82-2213G2

| ENGINE: F20A



HONDA ACCORD IV (CB) 2.0 i 16V (CB3) [01.1990-03.1993](Benzina)
 HONDA ACCORD IV Aerodeck (CB) 2.2 i 16V (CB8)[01.1991-12.1993](Benzina)
 HONDA ACCORD IV Coupé (CB, CC) 2.0 i 16V[01.1992-09.1993](Benzina)
 HONDA PRELUDE IV (BB) 2.2 i 16V Vtec (BB1)[02.1993-09.1996](Benzina)

82-2213G5

| ENGINE: F20A



HONDA ACCORD IV (CB) 2.0 i 16V (CB3) [01.1990-03.1993](Benzina)
 HONDA ACCORD IV Aerodeck (CB) 2.2 i 16V (CB8)[01.1991-12.1993](Benzina)
 HONDA ACCORD IV Coupé (CB, CC) 2.0 i 16V[01.1992-09.1993](Benzina)
 HONDA PRELUDE IV (BB) 2.2 i 16V Vtec (BB1)[02.1993-09.1996](Benzina)

82-2213GP

| OE: 13211-PH3-004 | ENGINE: F20A



HONDA ACCORD IV (CB) 2.0 i 16V (CB3) [01.1990-03.1993](Benzina)
 HONDA ACCORD IV Aerodeck (CB) 2.2 i 16V (CB8)[01.1991-12.1993](Benzina)
 HONDA ACCORD IV Coupé (CB, CC) 2.0 i 16V[01.1992-09.1993](Benzina)
 HONDA PRELUDE IV (BB) 2.2 i 16V Vtec (BB1)[02.1993-09.1996](Benzina)

82-2300G5

| ENGINE: EA82



SUBARU LEONE II 1800 4WD[01.1988-12.1990](Benzina)
 SUBARU LEONE II 1800 4WD[11.1984-12.1990](Benzina)
 SUBARU LEONE II 1800 Turbo 4WD[03.1989-12.1990](Benzina)
 SUBARU LEONE II 1800 Turbo 4WD[11.1984-12.1990](Benzina)

82-2301GP

| OE: 48291-5600 | ENGINE: EF10



SUBARU JUSTY I (KAD) 1000 4WD (KAD-A)[05.1987-11.1994](Benzina)
 SUBARU JUSTY I (KAD) 1000 4WD (KAD-A)[11.1984-12.1990](Benzina)
 SUBARU JUSTY I (KAD) 1000[05.1987-10.1995](Benzina)
 SUBARU JUSTY I (KAD) 1000[11.1984-06.1989](Benzina)

82-2302G2

| ENGINE: EF12



SUBARU JUSTY I (KAD) 1200 4WD (KAD-A)[05.1987-05.1991](Benzina)
 SUBARU JUSTY I (KAD) 1200 4WD[10.1986-12.1990](Benzina)
 SUBARU JUSTY I (KAD) 1200 4WD[10.1990-04.1996](Benzina)
 SUBARU JUSTY I (KAD) 1200[05.1987-10.1995](Benzina)

82-2302G5

| ENGINE: EF12



SUBARU JUSTY I (KAD) 1200 4WD (KAD-A)[05.1987-05.1991](Benzina)
 SUBARU JUSTY I (KAD) 1200 4WD[10.1986-12.1990](Benzina)
 SUBARU JUSTY I (KAD) 1200 4WD[10.1990-04.1996](Benzina)
 SUBARU JUSTY I (KAD) 1200[05.1987-10.1995](Benzina)

82-2302GP


| OE: 12111-KA00 | ENGINE: EF12



SUBARU JUSTY I (KAD) 1200 4WD (KAD-A)[05.1987-05.1991](Benzina)
 SUBARU JUSTY I (KAD) 1200 4WD[10.1986-12.1990](Benzina)
 SUBARU JUSTY I (KAD) 1200 4WD[10.1990-04.1996](Benzina)
 SUBARU JUSTY I (KAD) 1200[05.1987-10.1995](Benzina)

82-2401A

| OE: 12181-78400 | ENGINE: F8B



CHEVROLET MATIZ (M200, M250) 0.8 LPG[03.2005-20.0712](GPL)
 CHEVROLET MATIZ (M200, M250) 0.8[03.2005-20.1312](Benzina)
 DAEWOO MATIZ (KLYA) 0.8[09.1998-](Benzina)
 DAEWOO MATIZ Furgonato (KLA4) 0.8[08.1998-](Benzina)

82-2401A2

OE: 1218181051 | ENGINE: F8B



CHEVROLET MATIZ (M200, M250) 0.8 LPG[03.2005-20.0712](GPL)
 CHEVROLET MATIZ (M200, M250) 0.8[03.2005-20.1312](Benzina)
 DAEWOO MATIZ (KLYA) 0.8[09.1998-](Benzina)
 DAEWOO MATIZ Furgonato (KLA4) 0.8[08.1998-](Benzina)
 MARUTI 800 0.8[01.1991-](Benzina)

82-2402A

OE: 12181-78130 | ENGINE: F5A



SUZUKI ALTO 0.5[09.1985-05.1988] (Benzina)
 SUZUKI MIGHTY BOY 0.5[07.1985-10.1988](Benzina)

82-2403A

OE: 12100-82810-S3 | ENGINE: G10



SUZUKI SWIFT I (AA) 1.0 (SA310, AA41/43)[10.1983-03.1989](Benzina)
 SUZUKI SWIFT II 2 volumi /Coda spiovente (EA, MA) 1.0 (SF310, AA44) [03.1989-05.2001](Benzina)
 SUZUKI SWIFT II 2 volumi /Coda spiovente (EA, MA) 1.0 i (SF310, AA44) [01.1995-12.2005](Benzina)

82-2403A2

| ENGINE: G10



SUZUKI SWIFT I (AA) 1.0 (SA310, AA41/43)[10.1983-03.1989](Benzina)
 SUZUKI SWIFT II 2 volumi /Coda spiovente (EA, MA) 1.0 (SF310, AA44) [03.1989-05.2001](Benzina)
 SUZUKI SWIFT II 2 volumi /Coda spiovente (EA, MA) 1.0 i (SF310, AA44) [01.1995-12.2005](Benzina)

82-2403A5

| ENGINE: G10



SUZUKI SWIFT I (AA) 1.0 (SA310, AA41/43)[10.1983-03.1989](Benzina)
 SUZUKI SWIFT II 2 volumi /Coda spiovente (EA, MA) 1.0 (SF310, AA44) [03.1989-05.2001](Benzina)
 SUZUKI SWIFT II 2 volumi /Coda spiovente (EA, MA) 1.0 i (SF310, AA44) [01.1995-12.2005](Benzina)

82-2404A

OE: 12100-82810 | ENGINE: G13A



GEO METRO 1.3 GTI[01.1989-12.1998] (Benzina)
 GEO METRO 1.3 i[01.1989-12.1998] (Benzina)
 GEO METRO Cabriolet 1.3 i[01.1989-12.1998](Benzina)
 GEO METRO Tre volumi 1.3 i[01.1989-12.1998](Benzina)

82-2404A2

OE: 12100-82810025 | ENGINE: G13A



GEO METRO 1.3 GTI[01.1989-12.1998] (Benzina)
 GEO METRO 1.3 i[01.1989-12.1998] (Benzina)
 GEO METRO Cabriolet 1.3 i[01.1989-12.1998](Benzina)
 GEO METRO Tre volumi 1.3 i[01.1989-12.1998](Benzina)

82-2404A5

| ENGINE: G13A



GEO METRO 1.3 GTI[01.1989-12.1998] (Benzina)
 GEO METRO 1.3 i[01.1989-12.1998] (Benzina)
 GEO METRO Cabriolet 1.3 i[01.1989-12.1998](Benzina)
 GEO METRO Tre volumi 1.3 i[01.1989-12.1998](Benzina)

82-2405A

OE: 12100-608220A0 | ENGINE: G16A



SUZUKI BALENO (EG) 1.6 i 16V 4x4[07.1995-05.2002](Benzina)
 SUZUKI BALENO (EG) 1.6 i 16V[07.1995-05.2002](Benzina)
 SUZUKI BALENO 2 volumi /Coda spiovente (EG) 1.6 i 16V 4x4[07.1995-05.2002](Benzina)

82-2405A2

OE: 1210060821025 | ENGINE: G16A



SUZUKI BALENO (EG) 1.6 i 16V 4x4[07.1995-05.2002](Benzina)
 SUZUKI BALENO (EG) 1.6 i 16V[07.1995-05.2002](Benzina)
 SUZUKI BALENO 2 volumi /Coda spiovente (EG) 1.6 i 16V 4x4[07.1995-05.2002](Benzina)

82-2405A5

| ENGINE: G16A



SUZUKI BALENO (EG) 1.6 i 16V 4x4[07.1995-05.2002](Benzina)
 SUZUKI BALENO (EG) 1.6 i 16V[07.1995-05.2002](Benzina)
 SUZUKI BALENO 2 volumi /Coda spiovente (EG) 1.6 i 16V 4x4[07.1995-05.2002](Benzina)

82-2500A2

| ENGINE: AB



INNOCENTI MINI 0.55[01.1987-12.1991] (Benzina)
 INNOCENTI MINI 0.65[01.1984-12.1987] (Benzina)

82-2500A5

| ENGINE: AB



INNOCENTI MINI 0.55[01.1987-12.1991]
(Benzina)
INNOCENTI MINI 0.65[01.1984-12.1987]
(Benzina)

82-2501A

| ENGINE: CB



DAIHATSU CHARADE I (G10)
1.0[02.1981-02.1983](Benzina)
DAIHATSU CHARADE I (G10)
1.0[10.1977-02.1981](Benzina)
DAIHATSU CHARADE II (G11, G30) 1.0
(G11)[10.1983-03.1987](Benzina)
DAIHATSU CHARADE II (G11, G30) 1.0 D
(G30)[10.1983-03.1987](Diesel)

82-2501A5

| ENGINE: CB



DAIHATSU CHARADE I (G10)
1.0[02.1981-02.1983](Benzina)
DAIHATSU CHARADE I (G10)
1.0[10.1977-02.1981](Benzina)
DAIHATSU CHARADE II (G11, G30) 1.0
(G11)[10.1983-03.1987](Benzina)
DAIHATSU CHARADE II (G11, G30) 1.0 D
(G30)[10.1983-03.1987](Diesel)

82-2503A

| ENGINE: CL-T



82-2510A

| ENGINE: ED



INNOCENTI MINI 1.0 D[10.1985-](Diesel)

82-2510A2

| ENGINE: ED



INNOCENTI MINI 1.0 D[10.1985-](Diesel)

82-2511A

| ENGINE: HDC



DAIHATSU APPLAUSE I (A101, A111) 1.6
16V (A101)[06.1989-07.1997](Benzina)
DAIHATSU APPLAUSE I (A101, A111) 1.6
16V 4WD (A111)[06.1989-07.1997]
(Benzina)
DAIHATSU CHARADE III (G100, G101,
G102) 1.3 i (G102)[06.1988-12.1992]
(Benzina)

82-2511A2

| ENGINE: HDC



DAIHATSU APPLAUSE I (A101, A111) 1.6
16V (A101)[06.1989-07.1997](Benzina)
DAIHATSU APPLAUSE I (A101, A111) 1.6
16V 4WD (A111)[06.1989-07.1997]
(Benzina)
DAIHATSU CHARADE III (G100, G101,
G102) 1.3 i (G102)[06.1988-12.1992]
(Benzina)

82-2511A5

| ENGINE: HDC



DAIHATSU APPLAUSE I (A101, A111) 1.6
16V (A101)[06.1989-07.1997](Benzina)
DAIHATSU APPLAUSE I (A101, A111) 1.6
16V 4WD (A111)[06.1989-07.1997]
(Benzina)
DAIHATSU CHARADE III (G100, G101,
G102) 1.3 i (G102)[06.1988-12.1992]
(Benzina)

82-2805A

| ENGINE: ZD30



NISSAN ATLEON 35.15[10.2006-]
(Benzina)
NISSAN ATLEON 56.15[10.2006-]
(Benzina)
NISSAN CABSTAR E Pick-up 35.14 DCI
3.0 (F24M)[09.2006-12.2013](Diesel)
NISSAN CABSTAR E Pick-up 35.15 DCI,
45.15 DCI 3.0 (F24M)[09.2006-12.2013]
(Diesel)

82-2805A2

| ENGINE: ZD30



NISSAN ATLEON 35.15[10.2006-]
(Benzina)
NISSAN ATLEON 56.15[10.2006-]
(Benzina)
NISSAN CABSTAR E Pick-up 35.14 DCI
3.0 (F24M)[09.2006-12.2013](Diesel)
NISSAN CABSTAR E Pick-up 35.15 DCI,
45.15 DCI 3.0 (F24M)[09.2006-12.2013]
(Diesel)

82-2805A5

| ENGINE: ZD30




NISSAN ATLEON 35.15[10.2006-]
(Benzina)
NISSAN ATLEON 56.15[10.2006-]
(Benzina)
NISSAN CABSTAR E Pick-up 35.14 DCI
3.0 (F24M)[09.2006-12.2013](Diesel)
NISSAN CABSTAR E Pick-up 35.15 DCI,
45.15 DCI 3.0 (F24M)[09.2006-12.2013]
(Diesel)

82-5000A**OE: ME996533 | ENGINE: 4 M 40**

MITSUBISHI Canter Canter 35[07.1998-]
(Benzina)
MITSUBISHI Canter Canter
35[08.1996-12.1999](Benzina)
MITSUBISHI L 300 Furgonato (P0_W,
P1_W) 2.8 D[09.1995-10.1998](Diesel)
MITSUBISHI PAJERO II (V3_W, V2_W,
V4_W) 2.8 TD (V46W)[06.1994-10.1999]
(Diesel)

82-5000A2**| ENGINE: 4 M 40**

MITSUBISHI Canter Canter 35[07.1998-]
(Benzina)
MITSUBISHI Canter Canter
35[08.1996-12.1999](Benzina)
MITSUBISHI L 300 Furgonato (P0_W,
P1_W) 2.8 D[09.1995-10.1998](Diesel)
MITSUBISHI PAJERO II (V3_W, V2_W,
V4_W) 2.8 TD (V46W)[06.1994-10.1999]
(Diesel)

82-5000A5**| ENGINE: 4 M 40**

MITSUBISHI Canter Canter 35[07.1998-]
(Benzina)
MITSUBISHI Canter Canter
35[08.1996-12.1999](Benzina)
MITSUBISHI L 300 Furgonato (P0_W,
P1_W) 2.8 D[09.1995-10.1998](Diesel)
MITSUBISHI PAJERO II (V3_W, V2_W,
V4_W) 2.8 TD (V46W)[06.1994-10.1999]
(Diesel)